




# USER INSTRUCTIONS

## Limitorque Actuation Systems Modutronic 20 II

FCD LMENIM4002-00 – 08/06 (Replaces 401-12000)

**Installation**  
**Operation**  
**Maintenance**



# Contents

1	Introduction	5
1.1	Safety Information	5
1.2	Product Identification	6
1.3	Product Description	6
1.4	Product Features	6
1.5	Product Specifications	7
2	Operation	8
3	Definitions	10
4	Initial Checkout and Setup	11
4.1	Verify Correct Motor Rotation (Phasing) and OPEN/CLOSE Pushbutton Operation	11
4.2	Verify Limit Switch and Torque Switch Settings	13
4.3	Adjusting the Actuator Feedback Potentiometer	13
4.4	Connecting the Mod 20 II to Customer Command Signal Leads	14
5	Mod 20 II Presets	16
6	Calibration Procedure	18
7	Troubleshooting	23
8	Wiring Diagram	25
9	Schematic	28

# Figures

Figure 1.1 – Modutronic 20 II	6
Figure 2.1 – LY with a Modutronic 20 II and Associated Actuator Components	9
Figure 3.1 – Calibration Positions	10
Figure 4.1 – Standard Motor Rotation and Reverse Motor Rotation Wiring Diagrams for Dual-Voltage, Capacitor-Start, Induction-Run, and Single-Phase Low-Voltage Motors	12
Figure 4.2 – Standard Motor Rotation and Reverse Motor Rotation Wiring Diagrams for Dual-Voltage, Capacitor-Start, Induction-Run, and Single-Phase High-Voltage Motors	13
Figure 4.3 – Potentiometer Calibration Components Shown on a LY Position Indicator	14
Figure 6.1 – Calibration Adjustments for the Modutronic 20 II	18
Figure 6.2 – mA Calibrator Typically Connects (suggest Altek Model 334, <a href="http://www.altekcalibrators.com">www.altekcalibrators.com</a> ) to an Interconnect Board Terminal Strip or Terminal Strips Located in the Rear of a Panel- Mounted Mod 20 II	19
Figure 6.3 – Modutronic 20 II Board Component Locations	19
Figure 6.4 – FAIL TO Mode JP1 Jumper	22
Figure 8.1 – Modutronic 20 II Typical Three-Phase Wiring Diagram	26-27
Figure 9.1 – Modutronic 20 II Schematic Diagram	29-30

# Tables

Table 1.1 – Modutronic 20 II Specifications	7
Table 4.1 – Modutronic 20 II Terminal Connections	15
Table 5.1 – ON/OFF Potentiometer Turns for Desired Operating Time	16
Table 6.1 – DIP Switch Setting Levels of Deadband Accuracy	20



# 1

## Introduction

### 1.1 Safety Information

This Installation and Maintenance Manual was written for the user who is adding Modutronic 20 II capability to an existing actuator or who wants to adjust and/or troubleshoot a previously installed Modutronic 20 II Controller. These guidelines provide the information that is necessary to correctly install, set up, calibrate, and troubleshoot the Modutronic 20 II Controller.

Your safety and satisfaction are very important to Flowserve. Please follow all instructions carefully and pay special attention to safety.

The following methods will be used to emphasize text throughout this manual:

☠ **WARNING:** Refers to personal safety. This alerts the reader to potential danger or harm. Failure to follow the advice in warning notices could result in personal injury or death.

▲ **CAUTION:** Directs attention to general precautions, which, if not followed, could result in personal injury and/or equipment damage.

**NOTE:** Highlights information critical to the understanding or use of these products.

Bold text highlights other important information that is critical to system components.

CAPITALIZED text stresses attention to the details of the procedure.

Underlined text emphasizes crucial words in sentences that could be misunderstood if the word is not recognized.


The purpose of these emphasized blocks of text is to alert the reader to possible hazards associated with the equipment and the precautions that can be taken to reduce the risk of personal injury and damage to the equipment.

Read and become familiar with the material in these guidelines before attempting installation, operation, or maintenance of the equipment. Failure to observe precautions could result in serious bodily injury, damage to the equipment, or operational difficulty.

☠ **WARNING:** Read this Installation and Maintenance Manual carefully and completely before attempting to install or operate the Modutronic 20 II. Be aware of electrical hazards when installing or performing maintenance on the Modutronic.

## 1.2 Product Identification

Figure 1.1 – Modutronic 20 II



## 1.3 Product Description

The Modutronic 20 IITM is a solid-state integrated circuit-based controller. It is used to operate electric valve actuators in wastewater, petrochemical, and other industry applications requiring accurate modulation positioning. The standard input consists of a 4-20 mA signal generated by a process controller; the resulting output is used to accurately and repeatably position a valve actuator through conventional or solid-state switching of either single or three-phase AC power.

## 1.4 Product Features

- Accuracy and repeatability of positioning within 1% of full-scale for actuator stroke times greater than 30 seconds.
- Solid state circuitry for longer life and reliable service
- 4-20 mA command signal
- Can be used to control single or three-phase systems
- Jumper selectable Lock-in-Last or Fail-Closed configurations if command signal is lost
- Five parameters available for adjustment allows actuator/application match
- Adjustable ON and OFF motor control timers
- LED indicators display signal, power, and control status to simplify calibration and monitor performance

## 1.5 Product Specifications

Table 1.1 – Modutronic 20 II Specifications

Power Requirements	Derived from actuator supply Board power 18 VAC or 24 VDC ( $\pm 10\%$ ).3 VA
Control Signal	4-20 mA
Accuracy	Within $\pm 1\%$ (>30 second stroke)
Loss of Command Signal Selections	Fail-to-last-position Fail-to-minimum-signal-position
Temperature	-40°C to +85°C (operating)
Maximum Starts	Solid state reverser–600/hour
Per Hour	Electromagnetic contactor–100/hour
Maximum Direct Output Loading	Motor current–4.5 A Inrush, 3 A Holding
Dimensions	Mod 20–1.5”H x 3.25”W x 4”L Separate enclosure 11.7”H x 12.75”W x 17.4”L
Deadband	Adjustable between 1% and 10%
Resolution	1%
Linearity	1%
Humidity	To 95% (non-condensing)

# 2 Operation


The Modutronic 20 II receives an input signal, normally 4-20 mA, from the external process controller. This signal is compared (within the Mod 20 II circuitry) to the present position of the actuator as indicated by the signal from the Feedback Potentiometer attached to the gear train of the actuator. The comparison of these two signals generates an error signal that dictates the direction and distance the actuator needs to be driven.

Upon generation of the error signal, the appropriate output triac is enabled and 115-volt control power is directed to the output contactor (this may be an electromechanical contactor or a solid state reverser depending upon the application).

As the actuator drives toward the set-point, it enters a region surrounding the set-point where the control function within the Mod 20 II changes from a continuous power application to a pulsing mode (proportional band). The Mod 20 II continuously compares the valve's actual position to the desired set-point through its circuitry; motor pulsing is continued until the actuator is accurately positioned at the set-point. The point in the valve travel at which the pulsing mode is enabled and spacing/duration of the pulses are all user adjustable on the Mod 20 II.




Figure 2.1 – LY with a Modutronic 20 II and Associated Actuator Components



# 3 Definitions

Figure 3.1 – Calibration Positions



**Command Signal** Input signal provided by user to assign the desired valve position.

**Deadband** Adjusts the maximum allowable error signal. (Difference between the Position Command Signal and Position Feedback Potentiometer Signal). Selectable on the Mod 20 II DIP Switch. See Table 6.1 for DIP Switch setting chart.

**Proportional Band (Pulsing Window)** controls the point on the scale of valve travel that the motor begins the pulsing mode. (Increasing GAIN decreases the window width).

- Adjusting the GAIN Potentiometer fully CW ↻ (increasing GAIN/decreasing pulsing window), sets the GAIN to its maximum setting causing the motor to run continuously up to the Set-Point before power is turned off from the motor.
- Adjusting the GAIN Potentiometer CCW ↺ (decreasing GAIN/increasing pulsing window), causes the Mod 20 II to begin to “pulse” the motor on and off as it approaches the Set-Point.

**On Time** Adjusts the time that the electromechanical contactors or Solid-State Reversers are engaged while in the pulsing window.

**Off Time** Adjusts the time that the electromechanical contactors or Solid-State Reversers are disengaged while in the pulsing window.

**Set-Point** Desired stopping position for Mod 20 II; determined by the Command Signal.

**Span** Calibrates the Mod 20 II to align the Maximum Command Signal (normally 20 mA) with the Position Feedback Potentiometer at the open position.

**Zero** Calibrates the Mod 20 II to align the Minimum Command Signal (normally 4 mA) with the Position Feedback Potentiometer at the close position.

# 4 Initial Checkout and Setup

## 4.1 Verify Correct Motor Rotation (Phasing) and OPEN/CLOSE Pushbutton Operation

It is very important to check for correct motor rotation to insure that serious damage to the valve or other equipment does not occur. If the actuator motor rotates in the wrong direction, over-torque damage could occur to the equipment.

Prior to being shipped from the factory, each actuator is inspected to verify proper operation of the Torque and Position Limit Switch and to ensure that they function correctly (i.e. closes when the CLOSE pushbutton is depressed, opens with the OPEN pushbutton, etc.). These inspections are made with a properly phased power source connected as described in the actuator manual.

**▲ CAUTION:** To ensure proper operation and to prevent your actuator or other actuated equipment from damage, verify that your unit is properly connected to its power source.

**NOTE:** Your application may vary from the following standard wiring configurations for three-phase, single-phase, and DC motors. Refer to your actuator wiring diagram for user-specific wiring configuration.

### Three-Phase Motor

1. Using the Handwheel, move the valve to a midtravel position (midtravel position allows electrical operation in the valve “safe” area and keeps the OPEN and CLOSED Limit Switches from tripping while testing motor direction).
2. Test motor direction by momentarily pressing the OPEN pushbutton:
  - a. If the actuator moves toward CLOSED, immediately turn all power OFF and reverse the motor leads T1 and T3.


**NOTE:** Refer to your actuator wiring diagram for user-specific wiring configuration.

- b. If the actuator moves toward OPEN, the motor is wired properly for the application.

**Single-Phase Motor**


1. Using the Handwheel, move the valve to a midtravel position (midtravel position allows electrical operation in the valve “safe” area and keeps the OPEN and CLOSED limit switches from tripping while testing motor direction).
2. Test motor direction by momentarily pressing the OPEN pushbutton:
  - a. If the actuator moves toward CLOSED, immediately turn power OFF and proceed with the following instructions that match your application.
    1. Permanent Split Capacitor single-phase motors can be connected for opposite rotation by interchanging the leads T1 and T2 coming from the motor to the terminal strip.
    2. Single-voltage, capacitor-start, induction-run, single-phase motors interchange leads T2 and T3 coming from the motor to the terminal strip.
    3. Dual-voltage, capacitor-start, induction-run, single-phase motors can be connected for opposite rotation but the connection depends on whether the motor is operated on low voltage or operated on high voltage.
      - Low-voltage motors are connected for opposite rotation as shown in the changes between the Standard Rotation configuration and the Reverse Rotation configuration in Figure 4.1. This is accomplished by interchanging the two leads T1 and T3 coming from the motor with the two leads T6 and T8 also coming from the motor. No other changes are necessary.

Figure 4.1 – Standard Motor Rotation and Reverse Motor Rotation Wiring Diagrams for Dual-Voltage, Capacitor-Start, Induction-Run, and Single-Phase Low-Voltage Motors



- High-voltage motors are connected for opposite rotation as shown in the changes between the Standard Rotation configuration and the Reverse Rotation configuration in Figure 4.2. This is accomplished by interchanging two set of leads. First, interchange the leads T1 and T8 coming from the motor. Second, interchange leads T3 and T6 at the starting relays R1 and R2. No other changes are necessary.

Figure 4.2 – Standard Motor Rotation and Reverse Motor Rotation Wiring Diagrams for Dual-Voltage, Capacitor-Start, Induction-Run, and Single-Phase High-Voltage Motors



- b. Test Motor direction again by momentarily pressing the OPEN pushbutton. If the actuator moves toward OPEN, the motor is wired properly for the application. If not, check the wiring diagram for proper wiring.

## 4.2 Verify Limit Switch and Torque Switch Settings


Set the OPEN and CLOSE Limit Switch and the Torque Switch according to the instructions in the specific Actuator instruction manual.

## 4.3 Adjusting the Actuator Feedback Potentiometer

⚠ **WARNING:** Hazardous Voltage. Turn power OFF before calibrating the Feedback Potentiometer.

1. Shut off all power to the actuator.
2. Using the Handwheel, position the actuator to mid-travel (valve at the 50% position).
3. Disconnect the Potentiometer Wiring Harness from where it is plugged in or connected to a Terminal Strip.
4. Using an ohmmeter verify that the Potentiometer is in mid-travel position. The resistance from each End Connection to the Center Connection should be half of the full resistance of the Potentiometer. Example: 1000 ohm Potentiometer should read approximately 500 ohms from one of the End Connections to the Center Connection.

Figure 4.3 – Potentiometer Calibration Components Shown on a LY Position Indicator



5. If the reading is not correct, proceed to Step 6. If the reading is correct proceed to Step 7.
6.
  - a. Loosen the small Set Screw that retains the Potentiometer Drive Spur Gear to the Potentiometer Shaft.
  - b. Remove the Spur Gear to allow manual rotation of the Potentiometer Shaft.
  - c. Rotate the Potentiometer Shaft until the correct readings are obtained as described in Step 4.
  - d. Reposition the Spur Gear to re-engage with the Gear Train.
  - e. Proceed to Step 7.
7. Disconnect the ohmmeter and reconnect the Potentiometer wiring to original connection.

## 4.4 Connecting the Mod 20 II to Customer Command Signal Leads

⚠ **WARNING:** Hazardous Voltage. Turn power OFF before removing the actuator cover and connecting the command signal.

If the Mod 20 II was factory installed, the only connection required is the user input command signal leads (normally 4-20 mA). These connections should be made at the terminal strip in accordance with the wiring diagram enclosed with the actuator.

**NOTE:** if the unit does not have factory-supplied pushbuttons, refer to your wiring diagram to install a customer-supplied pushbutton station.

If retrofitting or adding a Mod 20 II to an existing actuator, use the following connection table and your wiring diagram for wire lead designations.

Table 4.1 – Modutronic 20 II Terminal Connections

Mod 20 II Terminals	Description	L120 Non-Compact Integral PC Board (61-825-0337-3)	
P1-1	18 VAC	18 VAC	See Note
P1-2	18 VAC	Power Source	See Note
P1-3	Negative 4-20 mA signal	TB1-5	-4-20 mA
P1-4	Positive 4-20 mA signal	TB1-4	+4-20 mA
P1-5	Potentiometer	TB1-8	
P1-6	Potentiometer (wiper)	TB1-9	
P1-7	Potentiometer	TB1-10	
P1-8	115 VAC (output common)	TB2-5	
P1-9	Close Contactor Output	TB2-6	
P1-10	Open Contactor Output	TB2-7	

Note: To Terminal Strip or Control Power Transformer with 18-Volt tap.

# 5 Mod 20 II Presets

**⚠ WARNING:** Hazardous Voltage. Turn power OFF before removing the actuator cover and connecting your command signal.

1. Turn off all power to the actuator to avoid equipment damage or personal injury.
2. Rotate the GAIN Potentiometer fully CCW ↶, then 15 turns CW ↷ to reach the midpoint of the Potentiometer. (See Figure 6.3 for Potentiometer locations).

**NOTE:** Each 30-turn Potentiometer will faintly ‘click’ when rotated to either the maximum or minimum position.

3. Rotate the ZERO Potentiometer fully CCW ↶, then 15 turns CW ↷ to reach the midpoint of the Potentiometer.
4. Rotate the SPAN Potentiometer fully CCW ↶, then 15 turns CW ↷ to reach the midpoint of the Potentiometer.
5. The following initial adjustments to the ON TIME and OFF TIME Potentiometers should be made to establish the proper pulsing sequence and duration for both electromechanical and solid state contactors.

a. Electromechanical contactor

1. Rotate ON TIME and OFF TIME Potentiometers fully CCW ↶, then 15 turns CW ↷ to the midpoint of the Potentiometer.
2. Rotate both the ON TIME and OFF TIME Potentiometers the number of times indicated in the Table 5.1 to obtain the desired operating time.

*Table 5.1 – ON/OFF Potentiometer Turns for Desired Operating Time*

Operation Time	On Time	Off Time
Less than 60 seconds	11 turns CW ↷	30 turns CW ↷
60-120 seconds	13 turns CW ↷	30 turns CW ↷
Greater than 120 seconds	17 turns CW ↷	25 turns CW ↷

b. Solid state reversers/VFDs

1. Rotate ON TIME and OFF TIME Potentiometers fully CCW ↶.
2. Rotate ON TIME Potentiometer 6 turns CW ↷.



3. Rotate OFF TIME Potentiometer 8 turns CW ↻.
4. This will provide a 0.04 second ON pulse and a 0.5 second OFF pulse.

**NOTE:**

- a. Rotating the ON TIME Potentiometer CW ↻ will increase the ON time.
- b. Rotating the OFF TIME Potentiometer CW ↻ will increase the OFF time.
- c. Adjusting one control (ON or OFF TIME Potentiometer) will affect the adjustment of the other control (ON or OFF Time Potentiometer).

**NOTE:**

- a. Electromechanical Starters should not exceed 100 total starts per hour.
- b. Solid-State Reversers should not exceed 600 total starts per hour.


# 6 Calibration Procedure

**⚠ WARNING:** Hazardous Voltage in Control Compartment. Exercise caution while calibrating the Mod 20 II with the Actuator Control Compartment open and power ON.

The purpose of performing the calibration procedure is to achieve the maximum accuracy obtainable for each particular actuator application while providing stable operation. The actuator gear ratio and many other factors determine the optimum calibration settings.

Four DIP Switches mounted on the Mod 20 II, as well as the ZERO, SPAN, GAIN, ON TIME, and OFF TIME potentiometers, are used to obtain the proper settings for your application. This procedure will proceed from the most accurate settings to the least accurate settings until unit stability is achieved.


Figure 6.1 – Calibration Adjustments for the Modutronic 20 II



1. Turn all power to the actuator OFF.
2. Verify that the procedures for the Initial Checkout and Setup (Section 4) and Mod 20 II Presets (Section 5) have been properly completed.

- To simulate a command signal, connect the mA Calibrator to the Command Input Leads on the Mod 20 II. These terminations are typically connected to the actuator Interconnect Board, or if the Mod 20 II is panel mounted, on the Rear Terminal Strip of the panel mount. In either case, these leads are labeled on your wiring diagram and will lead to connections 3 (P1-3[-]) and 4 (P1-4[+]) on the Mod 20 II.

*Figure 6.2 – mA Calibrator Typically Connects (suggest Altek Model 334, www.alktecalibrators.com) to an Interconnect Board Terminal Strip or Terminal Strips Located in the Rear of a Panel-Mounted Mod 20 II*



- Set the Mod 20 II DIP Switch #3 to the ON position and DIP switches numbered 1, 2, and 4 to the OFF position. This will set the error margin (DEADBAND) to 1% accuracy.

*Figure 6.3 – Modutronic 20 II Board Component Locations*




Table 6.1 – DIP Switch Setting Levels of Deadband Accuracy

Deadband Percentage	Dip Switch Number			
	1	2	3	4
± .5%	Off	Off	Off	On
± 1%	Off	Off	On	Off
± 1.5%	Off	Off	On	On
± 2.5%	Off	On	Off	Off
± 3.0%	Off	On	Off	On
± 3.5%	Off	On	On	Off
± 4.0%	Off	On	On	On
± 6.0%	On	Off	Off	Off
± 6.5%	On	Off	Off	On
± 7.0%	On	Off	On	Off
± 7.5%	On	Off	On	On
± 8.5%	On	On	Off	Off
± 9.0%	On	On	Off	On
± 9.5%	On	On	On	Off
± 10.0%	On	On	On	On

- ⚠ **WARNING:** Hazardous Voltage in Control Compartment. Exercise caution while calibrating the Mod 20 II with the Actuator Control Compartment open and power ON.
- 5. Set the mA Calibrator for the minimum signal level (normally 4 mA). The INPUT ACTIVE LED on the Mod 20 II should be illuminated. If not, reverse the polarity of the mA calibrator connections.
- 6. If the Actuator is equipped with an AUTO/MANUAL or LOCAL/REMOTE selector switch, turn the selector to the AUTO or REMOTE position.
- 7. Apply power to the Actuator and the Mod 20 II. The POWER ON LED on the Mod 20 II should be illuminated.
- 8. The Actuator may run in either direction and then stop;
  - a. If the unit stops, proceed to Step 9.
  - b. If the unit hunts back and forth, decrease the DEADBAND accuracy by changing the DIP Switch setting (refer to Table 6.1). Continue to Step 9.
  - c. If the unit runs all the way to one end of travel and stops, the Potentiometer Leads are probably wired backwards; reverse the Feedback Potentiometer's polarity by reversing the end leads at the Terminal Strip or on the Interconnect Board (if your application uses the Compact Integral Interconnect Board, the Plug-in Harness from the Pot to the Interconnect Board can be rotated 180° to reverse the polarity).
- 9. Adjust the ZERO point. This step calibrates the minimum or zero set-point to correspond to the end-of-travel of the Actuator and of the Feedback Potentiometer. Rotate the ZERO control slowly in the CW ↻ direction. This will cause the Actuator to be driven slowly towards the minimum control position (normally CLOSED). Continue rotating the ZERO control CW ↻ until the minimum (CLOSED) Position Limit Switch trips and the motor stops. The CLOSE LED should illuminate each time the Motor operates.
- 10. Adjust the control SPAN. This step calibrates the total SPAN of the control function and sets the maximum setting to correspond to the end-of-travel of the Actuator and of the Feedback Potentiometer.

- a. Set the mA Calibrator to the maximum command signal (normally 20 mA).
  - b. The unit may:
    - 1. Run toward the maximum position and stop short of the Position Limit Switch trip point, or
    - 2. Remain in position.
  - c. Rotate the SPAN Potentiometer slowly CW ↻. This will cause the Actuator to move slowly toward the maximum (normally OPEN) position. Continue rotating the SPAN control CW ↻ until the maximum (OPEN) Position Limit Switch trips and the motor stops. The OPEN LED should illuminate each time the Motor operates.
11. After initially setting the ZERO and SPAN setting, use the mA Calibrator to set the Command Signal back to the minimum setting (usually 4 mA); allow the actuator to run until it stops. Now fine-tune the ZERO setting for the position where the Limit Switch just trips.
  12. Use the mA Calibrator to set the Command Signal back to the maximum setting (usually 20 mA); allow the actuator to run until it stops. Now fine-tune the SPAN setting for the position where the Limit Switch just trips.

**NOTE:** If hunting continues during calibration procedure, it may be necessary to temporarily decrease the GAIN setting or increase the DEADBAND setting to get the ZERO and SPAN settings calibrated.

13. Adjust the ON TIME (optional). This step adjusts the period of time the Motor is energized in the pulsing mode when it is approaching the final set-point position.

**NOTE:** The ON TIME must be adjusted prior to adjusting the OFF TIME. Adjusting the ON TIME after adjusting the OFF TIME will require repeating the OFF TIME adjustment.

The duration of the ON TIME pulse to the Contactor/Solid State Reverser is increased by rotating the ON TIME Potentiometer CW ↻.

14. Adjust the OFF TIME (optional). This step adjusts the period of time the Motor is de-energized in the pulsing mode when it is approaching the final set-point position. This can also be described as the interval between ON TIME pulses. The duration of the OFF TIME pulse to the Contactor/Solid State Reverser is increased by rotating the OFF TIME Potentiometer CW ↻.

15. Adjust the GAIN. This step calibrates the width of the pulsing window around the set-point. This control works in conjunction with the four DIP Switches located on the Mod 20 II circuit board to determine the final accuracy of the unit in regard to set point position. The wider the pulsing window, the greater the distance from the set-point the unit enters the pulsing mode. It is desirable to minimize the pulsing window without causing the Actuator to hunt (oscillate uncontrollably around the set-point).

- a. For the initial calibration, ensure that DIP Switch 3 is ON and Dip Switches 1, 2, and 4 are OFF. This will provide 1% DEADBAND.


**NOTE:** If no DIP Switch is set to the ON position, the actuator will not operate.

- b. Make sure the GAIN Potentiometer is at the midpoint, then rotate the GAIN Potentiometer one turn CW ↻.
- c. Start with the mA Calibrator at 4 mA, then make a 5 mA change in the output of the mA Calibrator to provide a significant change of position; now watch the action of the actuator.

1. If the actuator hunts upon reaching the new set-point, reduce the GAIN control by turning in the CCW ↻ direction until the hunting stops and proceed to Step e.
  2. If the unit continues to hunt after the GAIN control adjustment, proceed to Step d.
  - d. Rotate the GAIN control fully CCW ↻ and then 15 turns CW ↻; adjust the DEADBAND to a less accurate setting and repeat the GAIN setting procedure starting with Step a. For example, if DIP Switch 3 is ON and DIP Switches 1, 2, and 4 are OFF the DEADBAND setting is at 1% accuracy; change the DIP Switch setting to 1½% accuracy and repeat the procedures 13a through 13e until the correct DIP Switch and GAIN control eliminates actuator hunting. See Table 6.1 for DIP Switch setting levels of deadband accuracy.
  - e. Rotate the GAIN control an extra ½ turn CCW ↻ to eliminate the possibility of future actuator hunting.
16. Set desired FAIL TO mode. See Figure 6.4.
- a. If LOCK-IN-LAST-POSITION is desired when loss of input signal occurs, install a jumper at JP1 to connect Pin 1 and 2.
  - b. If FAIL-TO-4mA-POSITION is desired when loss of input signal occurs, install a jumper at JP1 to connect Pin 2 and 3.

**NOTE:** Be sure to use one of the two jumper selections discussed above; FAIL-TO operation will be forfeited if JP1 is not used.

Figure 6.4 – FAIL TO Mode JP1 Jumper



17. Your Mod 20 II should now be properly calibrated.

# 7

## Troubleshooting

Symptom	Possible Cause	Corrective Action
Unit will not operate electrically in AUTO or MANUAL	1. No power to unit	1a. Verify Power Supply is electrically correct and present at actuator. 1b. Verify Power Leads are connected in accordance with the applicable wiring diagram. 1c. Inspect for Blown Fuse, tripped Circuit Breaker, or OPEN Disconnect Switch.
	2. Wiring problems	2a. (LYs with internal Mod 20 II board) Check push-on terminal between the Integral PC Board and the Micro Switches. Check for bad Micro Switches on SW Station.
	3. Starter wires loose	3a. Check all the connections on the Reversing Starter.
	4. Thermal overloads have tripped	4a. Measure continuity in the circuit. If you have an open circuit, wait for the motor to cool, then try to operate actuator. You may need to reduce the number of starts per hour.
Unit will not operate electrically in AUTO	1. No power to Mod 20 II	1a. Verify incoming 18 VAC between terminals P1-1 and P1-2 on Mod 20 II board.
	2. Bad Mod 20 II board	2a. Check board for burnt or broken components. Bypass Mod 20 II board using Pushbuttons to verify proper operation. See your specific wiring diagram for bypassing Mod 20 II board.
	3. Command Signal Leads reversed	3a. (L120 Interconnect PC Board) Check that the Command Signal Leads are wired to terminal TB16(+) and TB17(-).
	4. Bad Potentiometer	4a. Check the Potentiometer with an ohmmeter electrically in AUTO. Unplug the Pot from the Integral PC Board and take a meter reading between pins 7-1 and 7-2 or 7-2 and 7-3. The meter should have a steady reading. If the meter reading goes to zero or jumps around, verify that the Pot is centered. Replace the Pot if needed. Check for Cables that may have been pinched between the Housing Cover or Integral Assembly.
	5. All DIP switches turned Off	5a. Check DIP switches. Refer to Calibration Procedure (Section 6), Step 15a.

Continued on page 24


Symptom	Possible Cause	Corrective Action
Units run in one direction only	1. Shorted output	1a. Verify proper MANUAL direction operation. Using ammeter, verify proper command signal, verify all calibrations have been completed properly. If you still have difficulty calibrating the Mod 20 II after verifying the above settings, replace the Mod 20 II.
No LOCK-IN-LAST POSITION	1. Missing JP1 Jumper	1a. Locate JP1 Jumper on the Mod 20 II board and verify connections.
Unit will not follow signal	1. Bad Potentiometer or Potentiometer is not centered	1a. Check Pot as discussed in item #7. If Pot is OK, place the actuator at 50% and check the resistance between terminals 7-1 and 7-2 or 7-2 and 7-3 with an ohmmeter. See "Adjusting the Actuator Feedback Potentiometer" (Section 4.3).
Input signal does not result in full travel of the valve	1. Mod 20 II not calibrated correctly	1a. See Section 6 to review the calibration procedure for the Mod 20 II.
	2. ZERO and SPAN adjustments incorrect	2a. Recalibrate according to procedure in Section 6.
Large input signal variations result in little or no actuator movement	1. Improper analog Input Signal value	1a. Check for proper Input Signal value.
	2. Limit Switch	2a. Check for proper setting. (See appropriate actuator manual for setting the Limit Switches.)
	3. DEADBAND adjustment	3a. Check the DIP Switch accuracy adjustments shown in Table 6.1.
	4. ZERO and SPAN adjustments	4a. Recalibrate according to procedure in Section 6.



# 8

## Wiring Diagram

Figure 8.1 – Modutronic 20 II Typical Three-Phase Wiring Diagram



Valve shown in full open position


Rotor	Contact	Limit switch contact development			Function
		Fully Open	A	B	
Open	1	—	—	—	By-pass cir.
	2	—	—	—	Spare
	3	—	—	—	Ind light
	4	—	—	—	Open limit
	5	—	—	—	By-pass cir
Close	6	—	—	—	Spare
	7	—	—	—	Ind light
	8	—	—	—	Close limit
Int.1	9	—	—	—	Spare
	10	—	—	—	Spare
	11	—	—	—	Spare
Int.2	12	—	—	—	Spare
	13	—	—	—	Spare
	14	—	—	—	Spare
	15	—	—	—	Spare
16	—	—	—	Spare	

- ⑰ Closing torque switch interrupts control circuit if mechanical overload occurs during closing cycle
- ⑱ Opening torque switch interrupts control circuit if mechanical overload occurs during opening cycle

- NOTES**
1. .... Open contact
  2. — Close contact
  3. See certification sheet for voltage supplied. Transformer unused wired to be separately covered with insulating heat shrink tubing.
  4. Rotors int.1 & Int.2 Can be set at valve position full open, full closed or any position in between as indicated by points a and b.
  5. Add jumper on Is#8 between terminals (8) and (8C) for torque seating valves

- LEGEND**
- Open contact
  - ⊖ Close contact
  - ⊙ Opening coil
  - ⊙ Closing coil
  - Cpt-control power transformer
  - +Mechanical interlock
  - Th.OI-thermal overload contacts
  - ⊗ Red indicating
  - ⊗ Green indicating
  - Ss-selector switch (local-off-remote)
  - Pb1-open pushbutton
  - Pb2-stop pushbutton
  - Pb3-close pushbutton
  - Elec htr-compartment heater
  - Mtr htr-motor heater
  - Pot-potentiometer
  - Res-lamp resistors

Figure 8.1 – Modutronic 20 II Typical Three-Phase Wiring Diagram (continued)



# 9 Schematic

Figure 9.1 – Modutronic 20 II Schematic Diagram





Figure 9.1 – Modutronic 20 II Schematic Diagram (continued)



**Input Impedance (Zin)**

- Zin (4 mA) = 850 Ω
- Zin (8 mA) = 550 Ω
- Zin (12 mA) = 450 Ω
- Zin (16 mA) = 400 Ω
- Zin (20 mA) = 370 Ω





**United States**  
Limatorque  
5114 Woodall Road  
P.O. Box 11318  
Lynchburg, VA 24506-1318  
Phone: 434-528-4400  
Facsimile: 434-845-9736  
www.limatorque.com

**United Kingdom**  
Limatorque  
Abex Road  
Newbury  
Berkshire, RG14 5EY  
England  
Phone: 44-1-635-46999  
Facsimile: 44-1-635-36034

**Japan**  
Limatorque Nippon Gear Co., Ltd.  
Asahi-Seimei Bldg. 4th Floor  
1-11-11 Kita-Saiwai, Nishi-Ku  
Yokohama-Shi, (220-0004)  
Japan  
Phone: 81-45-326-2065  
Facsimile: 81-45-320-5962

**India**  
Limatorque India, Ltd.  
15/4, Mile Stone  
Mathura Road  
Faridabad 121002  
India  
Phone: 91-129-2276586  
Facsimile: 91-129-2277135

**Australia**  
Flowserve Australia, Pty. Ltd.  
14 Dalmore Drive  
Scoresby, Victoria 3179  
Australia  
Phone: 61 3 9759 3300  
Facsimile: 61 3 9759 3301

**Singapore**  
Limatorque Asia, Pte., Ltd.  
12, Tuas Avenue 20  
Singapore 638824  
Phone: 65-6868-4628  
Facsimile: 65-6862-4940

FCD LMENIM4002-00 Printed in USA. (Replaces 401-12000)

**To find your local Flowserve representative:**

For more information about Flowserve Corporation, visit  
[www.flowserve.com](http://www.flowserve.com) or call USA 1 800 225 6989

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can (and often does) provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the Installation Operation Maintenance (IOM) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

© 2006 Flowserve Corporation, Irving, Texas, USA. Flowserve is a registered trademark of Flowserve Corporation.