


Nordstrom Seat Principles Lubricated Tapered Plug Valves



The strength of a Flowserve Nordstrom tapered plug is its seat design. The tapered metal surfaces of the plug and body are fitted together during manufacture using successive steps of turning, grinding and lapping. The result is a nearly perfectly mated metal-to-metal seating surface.

Rotating the plug to close the valve creates a positive shearing action between the body and plug. Nordstrom tapered plug valves are strong and resilient by design, and are capable of closing through large obstructions. The precisely fitted tapered mating surfaces ensure the residue is cleaned from the seat each time the valve is closed.

When closed, there is a 15 to 18 degree overlap between the body and the plug seats on both sides of the flow passage. This provides positive shutoff—even without sealant—and provides bubble-tight shutoff when properly lubricated.

When the valve is opened, metal seats resist erosion from the high-velocity flow through the valve. There are no soft seats to be damaged.

Full seat protection, positive shutoff, shearing action and precise fit make the Flowserve Nordstrom lubricated tapered plug the seat design of choice.





United States

Flowserve Corp. Flow Control Flowserve Nordstrom Valves 1511 Jefferson Street Sulphur Springs, TX 75482 USA Telephone: 903-885-4691

or 4693 Fax: 903-439-3411

Latin America

Telephone: 903-439-3407 Fax: 903-439-3411

Other Countries

Telephone: 903-885-4692 Fax: 903-439-3404

To find your local Flowserve representative:

For more information about Flowserve Corporation, visit www.flowserve.com or call USA 1 800 225 6989

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can (and often does) provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the Installation Operation Maintenance (IOM) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

© 2004 Flowserve Corporation, Irving, Texas, USA. Flowserve is a registered trademark of Flowserve Corporation.