



Hydraulic Decoking System

Crosshead and Free Fall Arrestor

*Under its
Worthington[®],
Pacific[®] and IDP[®]
heritage names,
Flowserve hydraulic
decoking systems
are installed in
more than 150
refineries
worldwide.*



Crosshead Provides Function and Safety


Required to guide and center the rotary joint-drill stem-cutting tool assembly in the drum, the crosshead is designed to safely absorb all torque loads normally sustained from cutting operations.

Crossheads are available in two styles:

- Shoe-type
- Wheeled-type

The shoe-type design has two rectangular segments that are shaped to form the shoes. These shoes ride inside the beams of the structure.

The wheeled-type design utilizes four wheel blocks with spring loaded guides in two planes. These wheels ride on a track attached to the beams of the structure.




Experience In Motion

Free Fall Arrestor Ensures Safe Operation in Severe Environments


Both types of crossheads can be supplied with free fall arrestor (FFA) systems, which prevent equipment from collapsing in the event of a suspension failure. The free fall arrestor is a completely self-contained system (except the cables and rails) which is built into the crosshead. No electric or pneumatic connections are required for activation.

Additionally, the Flowserve free fall arrestor provides these benefits:

- Operator personnel and equipment safety in the event of steel wire rope failure
 - Prevents cutting assembly from falling and ramming coke bed
 - Prevents damage to ancillary equipment
- Proven reliability
- Automatic disengagement upon the restoration of the required tension




Arrestor Springs



Cable Gripping

- Compressed springs activate unique cable gripping devices that lock onto auxiliary arresting cables to stop the free fall
- The cable grippers are activated through linkage by compressed springs whenever main support cable tension is lost
- The auxiliary cables are suspended from damper spring assemblies that reduce peak shock loads on the tower and auxiliary cables during arrest



Rail Gripping

- Free fall arrestor grips on solid guide rails
- Proven equipment from elevator industry
- Guide rails and installation accessories are part of the Flowserve standard scope of supply

Bulletin PSS-90-6.4c (E) Printed in USA. September 2011.
© Flowserve Corporation

To find your local Flowserve representative:

For more information about Flowserve Corporation, visit www.flowserve.com or call +1 937 890 5839.

USA and Canada

Flowserve Corporation
5215 North O'Connor Blvd.
Suite 2300
Irving, Texas 75039-5421 USA
Telephone: +1 937 890 5839

Europe, Middle East, Africa

Flowserve Corporation
Parallelweg 13
4878 AH Etten-Leur
The Netherlands
Telephone: +31 76 502 8100

Latin America

Flowserve Corporation
Martín Rodríguez 4460
B1644CGN-Victoria-San Fernando
Buenos Aires, Argentina
Telephone: +54 11 4006 8700
Telefax: +54 11 4714 1610

Asia Pacific

Flowserve Pte. Ltd.
10 Tuas Loop
Singapore 637345
Telephone: +65 6771 0600
Telefax: +65 6862 2329